



AIR COOLER CLEANER

Liquid cleaner containing solvents and surfactants for on-line and off-line cleaning of charge air coolers.

FEATURES & BENEFITS



- Effective & economical way to remove oily contaminants from air coolers
- Can be used for in-service cleaning
- On-line cleaning saves time and maintenance costs
- Completely combustible in the cylinder
- Leaves no residues on the air cooler
- Has no harmful effects on the engine or the air cooling system
- Does not damage cylinder oil film
- Maintains and stabilizes air cooler efficiency
- Reduces maintenance costs and downtime
- Easy to use

PRODUCT DESCRIPTION

AIR COOLER CLEANER (ACC) is a liquid blend of highly active cleaning compounds. ACC has been developed for safe, fast and economical in-service cleaning of the air handling systems of turbocharged diesel engines.

By using ACC, airborne contaminants that have been carried into and deposited on scavenger air trunks, air coolers and inlet valves are removed. Thus, all surfaces are kept clean and free of deposits.

ADVANTAGES

- By using ACC and the VECOM MARINE ACC dosing system, fouling of air coolers is reduced so heat transfer and engine efficiency are improved. Pressure drops across the air cooler and air temperature after the air cooler are kept to a minimum.
- Fire hazards from the build-up of grease and residue are minimized.
- Downtime and expense of periodic dismantling of the air handling system for cleaning is eliminated.
- Scavenging efficiency is improved by the reduction of deposit build-up around scavenging ports.
- Reduces the adherence of airborne contaminants.

USAGE

ACC is suitable for all types of diesel engines. The ACC / fresh water mixture has no flash point and cylinder lubrication is not impaired.

For product characteristics and for the nature of special risks and safety advice consult our MSDS.
www.vecom-marine.com - sales@vecom-marine.com



DOSAGE

The suggested daily usage is 250 l/ton per air cooler. This is based on one injection every 24 hours. This can be varied based on performance of the pressure drops across the air coolers.

APPLICATIONS

ACC can be applied by immersion, circulation or injection. For immersion and circulation, cleaning time is reduced considerably by heating the chemical to maximum 50°C. If the air coolers are very dirty it may be advisable to use undiluted ACC by means of circulation method to thoroughly clean the system before commencing ACC injection treatment.

IMMERSION METHOD

(generally ACC is used undiluted)

The dismantled parts to be cleaned are laid in a tank specially designed for the purpose, which has been filled with undiluted ACC. Movement is achieved by means of compressed air. Wash surface with high-pressure water hose or compressed air. ACC can be reused for several cleanings. Cleaning time: 5 - 12 hours.

CIRCULATION METHOD

(for in-place cleaning - generally ACC is used undiluted) See diagram B


Arrange to collect ACC at bottom of unit with drain back to drum.

1. Circulate by pump and/or spray (airless spray or steady low-pressure flow - do not atomize) on deposits through access doors. A perforated pipe placed between tubes is effective for reaching normally inaccessible tubes.
2. Thoroughly saturate deposits and allow to stand for one hour minimum.
3. Wash off with high-pressure water hose and drain to collecting tank. *Diagram B*
4. Dry with compressed air.

CLEANING FUEL OIL HEATERS OR LUBE OIL COOLERS

See diagram C

For best results ACC should be circulated through the heat exchange unit for 6 to 8 hours, depending on the amount of deposits present and the length of time since the last cleaning. When ACC is used as a preventive maintenance item periodically, circulating times can be substantially reduced.



For product characteristics and for the nature of special risks and safety advice consult our MSDS.
www.vecom-marine.com - sales@vecom-marine.com



ACC solution can be saved and reused until it becomes thoroughly contaminated. Flushing unit with kerosene before using ACC will prevent excessive dilution. During cleaning, solids may accumulate in reservoir drum. These solids may be removed by allowing the solution to settle and decanting clean liquid from the top. When cleaning action of ACC has been reduced by excessive dilution with fuel oil, the material can then be dumped into the bunker tanks and then burned.




Diagram C

For circulating ACC a pump with a large discharge volume should be used in order to insure rapid flow through the unit. A 50 or a 200 l drum fitted with a wooden cover containing an opening for the discharge pipe can be used as a reservoir. Use enough ACC to fill the unit, piping and enough additional material to keep the reservoir one third full. Take pump suction from the reservoir and discharge into the lowest connection on the heat exchanger. Pipe the overflow from the highest point on the heat exchanger back into the reservoir. A fine mesh screen should be adapted to the reservoir return to remove large pieces, which become dislodged during the cleaning operation. To avoid the dislodging of loosened particles, a method of back-flushing can be used as indicated in schematic drawing showing recommended hood-ups for use of ACC.

INJECTION METHOD USING ACC (DAILY) UNDERWAY
(dilute with water as per dosage diagram) See diagram A

Simple, safe application of VECOM MARINE AIR COOLER CLEANER (ACC) is provided by use of the VECOM MARINE ACC Injection System. This system consists of a steel 6 l dosage tank, complete with all necessary valves, an atomizer and required fittings for 6x8 mm copper tubing. The dosage tank may be installed in any appropriate place in the engine room. Copper tubing (6x8 mm) is fitted from the dosage tank to the atomizer, from the dosage tank to the casing on the pressure side of the turbo blower (equalizing line), and from the ships' compressed air system to the atomizer.

By means of VECOM MARINE special ACC Injection System a mixture of ACC and fresh water in a ratio of 1:3 (observe the mixture ratio exactly) is injected into the air channel between the turbo blower and the air cooler. This is followed by a second injection of fresh water only. Injection procedure as per the ACC Injection System diagram is as follows:

1. Fill the dosing tank with the required quantity of ACC fresh water mixture. Close the tank.
2. Open valve 1 (compressed air for atomizer).
3. Open valve 2 and 3; following equalization of pressure to the scavenging air line the ACC / fresh water mixture is injected in about 5-10 minutes.
4. Close valves 1, 2 and 3.
5. Open valve 4 to vent air from the tank.
6. Fill the tank with fresh water. Close the tank. Repeat steps 2 - 5.




Diagram A

For product characteristics and for the nature of special risks and safety advice consult our MSDS.
www.vecom-marine.com - sales@vecom-marine.com




STANDARD PACKING

AIR COOLER CLEANER is usually available in steel drums of 25 l.


INSTALLATION DRAWINGS

These installation drawings are only a guide for typical installations. Air trunking dimensions, configuration and baffles arrangement may differ between engines of the same model. Physical inspection is necessary to ensure that nozzles are correctly sited and installed. These drawings are not to scale. All dimensions are in millimetres.

MAN B&W K.. MC




MAN B&W L/S.. MC




For product characteristics and for the nature of special risks and safety advice consult our MSDS.
www.vecom-marine.com - sales@vecom-marine.com




STORK-WARTSILA 20TM410



DEUTZ TBD 234V8



PIELSTICK



For product characteristics and for the nature of special risks and safety advice consult our MSDS.
www.vecom-marine.com - sales@vecom-marine.com